

Right IJ used for
ECMO
cannulation,
typically 15-19 F
(VV return)

Please place:
Left IJ
TLC/Swan-Ganz
for
medications

Please place:
Right radial
arterial line.

RFV or LFV used
for ECMO
cannulation,
typically 24-28 F
(VA/VV drain)

RFA/LFA used
for ECMO
retrograde
cannulation,
typically 15-19
F (VA return)

*RSFA/LSFA
antegrade
reperfusion
cannula,
typically 8 F

Have on hand:

At least two manifolds, at least 2 liters of NS, 500 ml bottle of NS, at least 2 units of cross matched PRBC (if able), sterile drapes, sterile attire for at least two people, crash cart, sedation/analgesia, neuromuscular blockade, various vasopressors/inotropes, heparin, ACLS medications.